




93500 Rim Flange Clamp

Rim Flange Clamp

- Clamps to bead seat band to assist in seating for inflation
- Used to assist in removal of bead seat band during tire service
- Sold individually but frequently used in pairs



ameintl.net

2347 Circuit Way

Brooksville FL, 34604

352-799-1111 - sales@ameintl.net

