


### 9.4 Exploded view HFN-8, -9, -10, FN-8, -9, -10



**9.5 Spare part list HFN-8, -9, -10, FN-8, -9, -10**

Item	OKU id. No.	Qty	Designation
1	00000119	1	Hexagon screw
2	00000677	1	Washer
3	00000759	1	Retaining washer
4	00000809	1	Circlip
5	00000303	1	Grub screw
6	00022605	2	Adjusting washer
7	00022610	1	Adjusting washer
8	00025370	2	Self-tapping screw
9	00350857	1	Spring (for HFN / FN-8)
	00350904	1	Spring (for HFN / FN-9)
	00350905	1	Spring (for HFN / FN-10)
10	00350891	1	Shaft
11	00350897	1	Feeding tube 8,3 (for HFN / FN-8)
	00350898	1	Feeding tube 9,3 (for HFN / FN-9)
	00350899	1	Feeding tube 10,3 (for HFN / FN-10)
12	00350918	1	Bracket
13	00650033	1	Base plate
14	00650034	1	Feed wheel
15	00130403	1	Gear motor (for FN-8, -9, -10)
16	00004106	1	Feeding hose (for HFN / FN-8)
	00004107	1	Feeding hose (for HFN / FN-9)
	00004104	1	Feeding hose (for HFN / FN-10)
	00130401	1	Wall holder (accessory)

**EN**