

Body Assembly


AME International
 2347 Circuit Way
 Brooksville FL 34604
 Phone 352-799-1111 Fax 352-799-1112
 sales@ameintl.net

No.	Description	QTY	
73200-601	Body	1	
73200-602	Swinging frame	1	
73200-603	Up pneumatic cylinder	1	
73200-604	Pneumatic cylinder shaft	2	
73200-605	Shaft 1	4	
73200-606	Motherboard of pneumatic control box	1	
73200-607	Pneumatic control box	1	
73200-608	Spreading pneumatic cylinder	1	
73200-609	Connection union	1	
73200-610	Adjustive pipe 1	1	
73200-611	Short spread hook	1	
73200-612	Alignment unite element	2	
73200-613	Lever unite element	2	
73200-614	Power line bracket	1	
73200-615	Staff shaft	3	
73200-616	Long spread hook	1	
73200-617	Adjustive pipe 2	1	
73200-618	Swing Frame	2	
73200-619	Branch Union	4	
73200-620	Lever unite element	1	
73200-621	Shaft 3	1	
73200-622	Connection board	4	
73200-623	Short pulling pole	2	
73200-624	Pulling Pole	1	
73200-625	Up & down bracket	1	
73200-626	Shaft 2	1	
73200-627	Connecting-rod shaft	4	
73200-628	Shaft 2	1	
73200-629	Swing cover	1	
73200-630	Tools tray	1	
73200-631	Column hexangular bolt	M8x10	6
73200-632	Washer	8	6
73200-633	Ceasing nut	M12	8
73200-634	Hexangular bolt	M8x30	2
73200-635	Hexangular nut	M8	7
73200-636	Washer	12	12
73200-637	Hexangular bolt	M12x40	8
73200-638	Ceasing nut	M16	2
73200-639	Washer	16	2
73200-640	Handle ball	B-M10x32	2
73200-641	Coarse thread Hexangular flat bolt	M10	2
73200-642	work light		1
73200-643	Hexangular flat bolt	M10	1
73200-644	Compressing spring		2
73200-645	Column hexangular bolt	M10x50	2
73200-646	Hexangular nut	M12	8

AME International
2347 Circuit Way
Brooksville FL 34604
Phone 352-799-1111 Fax 352-799-1112
sales@ameintl.net

No.	Description		QTY
73200-647	Spring washer	12	2
73200-648	Column hexangular bolt	M6x12	4
73200-649	Spring washer	6	2
73200-650	Air regulator		1
73200-651	Spring washer	8	5
73200-652	Big flat washer	6	2
73200-653	Column hexangular bolt	M5x16	2
73200-654	big flat washer	5	2
73200-655	Electron transformer		1
73200-656	Crossed set bolt	M4x40	6
73200-657	Washer	4	12
73200-658	Handle valve		2
73200-659	Spring washer	4	6
73200-660	Hexangular nut	M4	6
73200-661	Washer	5	12
73200-662	Column hexangular bolt	M5x10	4
73200-663	Spring washer	5	2
73200-664	Hexangular nut	M5	2
73200-665	Loop		1
73200-666	Power thread		1
73200-667	Metal quick connector		1
73200-668	Shaft spring loop	20	14
73200-669	Washer	6	4
73200-670	Hexangular nut	M6	2
73200-671	Column hexangular bolt	M8x12	1

AME International
2347 Circuit Way
Brooksville FL 34604
Phone 352-799-1111 Fax 352-799-1112
sales@ameintl.net



Pneumatics Assembly

AME International
 2347 Circuit Way
 Brooksville FL 34604
 Phone 352-799-1111 Fax 352-799-1112
 sales@ameintl.net

No.	Description	Qty
73200-667	Metal quick connector	1
73200-701	Pneumatic cylinder cover	2
73200-702	pneumatic cylinder canister	1
73200-703	Cylinder bottom	2
73200-704	Connecting staff	4
73200-705	Connecting staff	4
73200-706	Washer	2
73200-707	Piston staff	2
73200-708	Pneumatic culinder canister	1
73200-711	O-Ring	2
73200-712	Washer	16
73200-713	Ceasing nut	16
73200-714	PU pipe	2
73200-715	Dustproof seal	2
73200-716	PU pipe	1
73200-717	Quick insert union	1
73200-718	Metal quick connector	1
73200-719	PU pipe	1
73200-720	Quick insert right angle connector	4
73200-721	PU pipe	1
73200-722	Union	2
73200-723	Hexangular flat nut	2
73200-724	Piston	2
73200-725	Column hexangular bolt	2
73200-726	PU pipe	1
73200-727	PU pipe	4
73200-728	quick insert middle union	1
73200-729	subminiature silencer	4
73200-730	handle valve	2
73200-731	quick insert middle union	4
73200-732	PU pipe	1
73200-733	speed adjusting union	2
73200-734	quick insert straight union	2
73200-735	quick insert upright union	1
73200-736	PU pipe	1
73200-737	o rubber ring	4
73200-738	oil free piston	2

AME International
2347 Circuit Way
Brooksville FL 34604
Phone 352-799-1111 Fax 352-799-1112
sales@ameintl.net