

Cod.	Description	Cod.	Description	Cod.	Description	Cod.	Description	Cod.	Description
0013	Dowel	0314	Fitting	1092	Rod for Stop Bar	1306	Screw	KITPROL	EXTENSIONS WITH BOX
0026	Seal	0373	Knobs	1101	Seal	1307	Frame kit	KC318N	YAK 318N CYLINDER SEALS KIT
0033	Washer	0376	Wheel	1102	Motor Piston	1308	Fitting	KA318N	YAK 318N MOTORPUMP SEALS KIT
0040	Ball	0378	Distributor	1103	Cylinder	1309	Pipe for Tank Oil	KB318N	YAK 318N BLOCK SEALS KIT
0041	Spring	0390	Screw	1104	Pumping Element for Motor Unit	1311	Fitting	KD953	KIT DISTRIBUTOR COMPLETE WITH FITTINGS
0047	Seal	0395	Cap for Handlebar	1105	Seal Holder Nut	1312	Screw		
0050	Over Pressure	0396	Screw	1106	HP seal	1313	Spacer		
0051	Spring	0398	Nut	1107	Pumping Element Guide	1314	Casing		
0052	Adjustment Screw	0399	Fitting	1108	Pump Body	1400	Extension holder		
0063	Seal	0390	Fitting	1109	Filter	1401	Screw		
0065	Seal	0396	Safety Cock	1110	Washer	2032	Washer		
0071	Filler	0420	Silencer	1111	Screw	2058	Handlebar Fixing Bush		
0075	Seal	0429	Ball	1112	Cap for Overpressure Valve	2391	Fitting		
0077	Spring	0433	Quick Coupling	1117	Valves Cap				
0078	Nut	0508	Washer	1118	Hydraulic Block Body				
0080	Piston pin	0510	Overpressure Valve Body	1119	RH Baseament Blade				
0084	Spring	0518	Valve Cap	1120	LH Baseament Blade				
0085	Ball	0521	Ball	1121	Screw				
0088	Quick Discharge Valve	0541	Dowel	1132	Scraper Ring				
0089	Quick Return Valve Piston	0703	Screw	1133	Scraper Ring				
0090	Seal	0706	Piston Return Spring	1141	Filter Holder Nipple				
0091	Pin Holder	0709	Seal	1142	Tank kit				
0092	Washer	0716	Fitting	1143	Tank air inlet Nipples				
0093	Screw	0726	Cap	1152	BLOCK UNIT				
0094	Stop	0750	Fitting	1159	Filter Holder Bolt				
0095	Washer	0757	Rubber Motor Valve	1160	Screw				
0107	Cap	0762	Seal	1162	Filter fixing screw				
0106	Spring	0763	Valve Body	1163	Filter				
0115	Small Plate	0795	Oil plug	1164	Cock				
0116	Short Extension	0935	VACUUM UNIT	1165	Seal				
0117	Long Extension	0944	WHEEL UNIT	1171	HP seal				
0118	Fitting	0953	HANDLE UNIT	1192	BASEMENT - CYLINDER UNIT				
0119	Washer	0965	TANK UNIT	1203	Piston 80				
0130	Piston	0970	FRAME UNIT	1204	Piston 60				
0137	Seal	0975	MOTOR PUMP UNIT	1221	Cylinder 110				
0197	Snap Ring	1004R	Rilsan Pipe	1222	Piston 110				
0202	Plate	1004R	Rilsan Pipe	1230	Baseament				
0206	HP seal	1023	Scraper Ring	1254	Washer				
0210	HP back-up ring	1024	HP Seal	1288	Big Handlebar Unit				
0263	Cap for Discharge Valve	1028	Nozzles for Vacuum Unit	1290	Screw				
0264	Piston	1029	Inlet Nipples for Air Descent	1292	Spring				
0265	Piloted Discharge Valve	1035	Check Valve Nipples	1293	Spring				
0266	Nipples for Silencer	1046	Spring to Drawing	1294	Long stop bar				
0267	Silencer	1049	Washer	1295	Washer				
0299	Spacer	1066	Vacuum unit Body	1296	Nut				
0302	Screw	1067	Stop Bar Lever Fixing Support	1300	Head for Motor				
0304	Washer	1083	Wheel Hub	1305	Casing				















