



# INSTRUCTION MANUAL

## Parts List For

### 10 Ton Low Profile Steel Cylinder Kit

#### Model 13075

## ! WARNING !

To avoid serious personal injury, always wear proper protective gear, such as hard hats, safety glasses, gloves, and steel toe shoes when using hydraulic equipment. Failure to chock the wheels and crib the vehicle can result in Serious injury or death.

Always deflate tires before removing a wheel, a rim, or part of a rim clamp or nut. If you do not deflate the tire, the tire could explode, causing serious injury or death.

Always stand to one side of the rim when using the bead breaker. Standing to one side of the bead breaker allows you to maintain control of the bead breaker. If it is not seated properly and flies off the rim, the bead breaker could cause serious injury or death.



### REPLACEMENT PARTS

Not all components of the cylinder are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence.

MODEL: 13075

Item	Part Number	Description	Qty	Item	Part Number	Description	Qty
1	N/A	Cylinder Housing	1	13	13075-008	Rubber Plug	1
2	13075-001	Return Spring Assy	1	14		Cylinder	1
3	13075-002	Ram Plunger	1	15	13070-009	Adapter III PP	1
4	*	Back-up Ring	1	16	13070-011	Adapter II PP	1
5	*	O-Ring	1	17		Adapter I PP	1
6	*	Special Washer	1	18	13075-016	Saddle	1
7	13075-003	Bolt	1	19	13075-013	Carrying Case	1
8	13075-004	Upper Bearing	1	20	13075-016- 1	O-Ring	1
9	*	Dust Seal	1	(*)	13075-015	Seal Kit,	1
10	13075-005	Bolt	1	(*) indicates items included in, and available only as part of Seal Kit  N/A- Part is not available as replacement			
11	13075-006	Coupler, Female	1				
12	13075-007	Dust Cover	1				

