



**Repair Parts**

No.	Description	Part No.	No.	Description	Part No.
1.	Air Tank	N/A	6.*	Discharge Valve	03.102
2.	Safety Release Valve	05.102	7.	6" Pipe Nipple	02.104BS
3.	3/4" - 1/4" Bushing	01.107	8.	Pressure Gauge	01.106
4.	Ball Valve	04.103	9.	Decal	01.114
5.	Flared Barrel	6813			

\*Includes Handle

**Order parts from your distributor or jobber.** When ordering parts always give the following information: *Part Number, Description and Serial Number of Your Machine.*

**REMINDER: Always exercise caution when using compressed air.**

